# SWEEP BOLLARD INSTALLATION INSTRUCTION








#### PHYSICAL


Body	Aluminium Extruded Profile	
Finish	Polyester Powder Coated	
Dimensions	Ø165xH500/Ø165xH1000	
OPTICAL		
Diffuser	Clear Polycarbonate	
Light distribution	Assymetric	
ELECTRICAL		
Light source	LED	
CRI	>80	
ССТ	3000K-4000K-5000K	
Driver	Electronic included   50-60Hz 220-240VAC Non-Dimmable Driver 1-10V dimming or DALI on request	
Operating Temperature	-30°C ~ +50°C	
Humidity	10% ~ 90%RH	


Packing list			
	Dana wiata		
	Base plate templates	1PCS	
	Screw fixing plate	1PCS	
	Screw M5*16	5PCS	
	Screw M8	3PCS	
	Nut M8	3PCS	


























## DIMMABLE





# **TECHNICAL DRAWING**



### **SAFETY INSTRUCTIONS:**

- Please read this instruction carefully before the commencement of installation and pass it on to the user of the equipment.
- The installation must be carried out by qualified personnel.
- Disconnect the main voltage, before starting the installation work.
- The light source of this luminaire is not replaceable when the light source reaches the end of its useful life, the entire luminary is substituted.
- This fixture is not suitable for handheld use. It should be mounted in a fixed and safe place.
- Improper handling of the components or the luminary itself could damage the correct function of this product, thus avoiding the manufacturer's warranty.
- Luminary is suitable for outdoor use.
- BEYOND LIGHTING FACTORY is not responsible for the improper use or modifications made to the product.
- In case the external flexible cable or cord of the fixture is damaged, to avoid danger it should only be replaced by the manufacturer or equivalent qualified personnel.
- For possible malfunctions, the defective products must be disassembled and delivered to the manufacturer company without any intervention. During the dismantling of the product, the cable insulation should not be damaged. Also, the cable should not be cut too close to the product. Enough cable should be left to take out the fixture.
- The report, which will be formed as a result of the tests to be made regarding the malfunction, will be shared with the customer, and if necessary, the product will be delivered back to the customer by eliminating the problems according to the warranty.